

Fixed (Dummy) Trim Installation Instructions



Figure 1

A 6mm allen wrench is needed for installation.

Note: The inside backplate has through holes and the outside backplate has threaded lugs.

Depending on backplate style, an additional hole may need to be drilled in the door to complete installation.

1. Determine handing. Remember handles will be perpendicular to backplate, pointing either to the left or right.
2. Slide handle into backplate so square corners of the handle neck match up with notches in backplate.
3. Insert screw from back side of plate into handle neck and firmly tighten down with the included 6mm allen wrench.

Figure 2

1. If not already done, pre-drill 10mm (.394") holes through door stile to accept backplate screws and lugs.
2. Mount handle and backplate assemblies to interior and exterior of door with screws provided.

